

# Parts used for service

## BM PS 15 pump station from 2004 and before.

To ensure the reliability, service and maintenance is very important.

In the manuals you can find the service scheme for your machine,

Please remember to read the manual before using the machine.

In the service scheme you will also find the daily checks you must remember.

### Parts for every 250 hours

#### PS 15

- Oil 2 litres on engine (504920) Q8 FS 10W-40 or similar
- Oil filter 1 pc. on engine (503151)
- Fuel filter 1 pc. on engine (503152)
- Hydraulic filter 1 pc. on Hydraulic system (500490)

Remember to check all air filters regularly (replacement schedule can vary from different work conditions)

#### Boiler

- Fuel filter 1 pc. to each oil burner (only if mounted) (500413)

### Parts for every 1000 hours / 6 months

#### PS 15

- Oil 2 litres on engine (504920) Q8 FS 10W-40 or similar
- Oil filter 1 pc. on engine (503151)
- Air filter element 1 pc. on engine (503153)
- Fuel filter 1 pc. on engine (503152)
- Hydraulic filter 1 pc. on hydraulic system (500490)
- Oil 65 litres on hydraulic system (503626) Q8 HANDEL 46 or similar

Remember to check all air filters regularly (replacement schedule can vary from different work conditions)

Change of the hydraulic oil can depend of environment, check the oil before changing.

#### Boiler

- Fuel filter 1 pc. to each oil burner (only if mounted) (500413)



Borum Industri A/S, Højvangsvej 10,  
Hadbjerg, DK-8370 Hadsten, Denmark, CVR nr. DK 19085694  
Tel: + 45 87 613 213, Fax: + 45 87 613 214,  
www.borum.as • e-mail: info@borum.as

– it's straightforward

# Parts used for service

## We recommend doing the following minimum each year:

PS 15

To check/renew coolant

Boiler

To change heat oil, and make service on the oil burner

- Heat oil                      Litre depending of size (only on ID boilers) (500383) Q8 GLUCK H or similar
- Nozzle                        1 pc for oil burner (only if mounted)

Size of nozzle is depending of boiler type see manual for burner

## We recommend doing the following minimum every two years:

PS 15

To change belt

- V-belt                        1 pc. for generator on engine                      (503146)

To change water and fuel pipes clamps

To change fuel pipes and clamps

Borum Industri A/S, Højvangsvej 10,  
Hadbjerg, DK-8370 Hadsten, Denmark, CVR nr. DK 19085694  
Tel: + 45 87 613 213, Fax: + 45 87 613 214,  
www.borum.as • e-mail: info@borum.as



– it's straightforward